




Re-subscribing to the Push Service for the new Android App version 7.
Before you begin if you are your home network (wifi), temporarily turn that off in your phone settings before doing this procedure so you can connect to the DVR in the “Away” mode.



Tap on the Menu Button




Tap on the Alarm Manager




Tap on the Subscribe


Your setting might list “Home” or “Away”. The Away device is the one that we setup with the Push Notice. If it has “Close” to the right of the name, that indicates it is not subscribed. Tap on the “Away” Close



Tap on "Away" Close




Tap on Toggle to turn enable




If Live is selected, Tap and reselect Video

Tap Local Alarm


On the Local Alarm screen, you will select the alarm inputs corresponding to the cameras you want to get the Video Push from. If in doubt of exactly which input, you can select them all. Once you have selected the Alarm inputs, use the top left icon "<" to go back to the "Subscribe" Menu



Tap on the Blue Check Mark on the top right corner to save your setting



Tap the "<" to go back to "Event List" screen



Indicates Subscribed

Tap on the Menu button on the top left and select Live Preview, the app is now subscribed to the Push Service and ready to go.

